



Figure 5. - Cylinders, Cylinder Heads

Item	Part #	Description	Notes	Q-ty
1	IMZ-8.108-01052	LH cylinder head assy	Installed thru 2005	1
1	IMZ-8.108-01052-10	LH cylinder head assy	Installed from 2006 Model Year (includes mounting studs for exhaust)	1
2	IMZ-8.108-01051	RH cylinder head assy	Installed thru 2005	1
2	IMZ-8.108-01051-10	RH cylinder head assy	Installed from 2006 Model Year (includes mounting studs for exhaust)	1
3	IMZ-8.108-01031	Cylinder assy	Must Specify size when ordering (A, B, C) as stamped on cylinder. Note that item #6 is not included. Must order sealing cap separate.	2
4	IMZ-8.108-01301	Cylinder	See fig. 5, #3 - Available as assembly only	2
5	IMZ-8.108-01039	Push rod tube assy		4
6	IMZ-8.108-01309	Sealing cap		4
7	IMZ-8.103-01515	Valve		2
8	IMZ-8.103-01303	Cylinder gasket		2
9	IMZ-8.108-01504	Cylinder head gasket		2
10	IMZ-8.103-01517	Head cover gasket		2
11	009414-P27	Stud M8x55, head cover fastening		2
12	62-01520	Nut, cylinder head cover fastners		2
13	252005-P27	Washer 8		6
14	IMZ.8-1236-12155	Header Pipe Gasket	NOT PICTURED - Installed from 2006 Model Year	2
15	IMZ.8-103-01508	Rocker Arm Guide Bushing	Not Pictured - Used to align rocker arm to head	4